

RAC - 2 BAND CUMMERBUND



1. Lay rear carrier flat as shown. Open the two velcro flaps on rear plate pocket.



2. After you determine your desired placement height, use the included elastic cord and insert through both sets of folded webbing.



3. Weave the elastic cord through the ends of the 2 Band cummerbund and pass through the folded webbing just below the cummerbund. Tie a knot to secure the cord. The extra slack can be tightened or loosened to accommodate personal preference.



4. Fold the two velcro flaps back together.