

Installation and Care Instructions

Maverick Mud Flaps(Rear)

Please read all instructions before installation.

1. **Tools and Materials Needed**

- 9/32" Socket Wrench (For Factory Hardware)
- 1/4" Socket Wrench (For Included Hardware)
- 4 - 1.25" Screw w/Washer (Included)

Remove Factory
Hardware as
shown here:



Figure 1

2. **Installation Preparation**

- Remove factory hardware. (See **Figure 1** for location)

3. **Installation**

- Align mud flap, and tighten each screw (Included) so it's snug and not overtightened as shown in **Figure 2**.

Repeat steps for other side

Use Included
Hardware as
shown here:



Figure 2