

Installation and Care Instructions

Maverick Mud Flaps(Front)

Please read all instructions before installation.

1. **Tools and Materials Needed**

- 7/16" Socket Wrench (For Included Hardware)
- 4 - 1" Bolt w/Washer (Included)
- 4 - Speed Clip (Included)

2. **Installation Preparation**

- Remove factory push in rivets. (See **Figure 1** for location)

3. **Installation**

- Pull back the inner wheel liner and add speed clips as shown in **Figure 2**. Place inner wheel liner back to factory position, align mud flap, and tighten each screw so it's snug (not overtightened) as shown in **Figure 3**.

Repeat steps for other side

Remove Factory
Push in Rivets
as shown here:



Use Included
Speed Clips
as shown here:

