

Installation and Care Instructions

TUNDRA Door Sill Protection Overlays

Please read all instructions before installation.

1. **Tools and Materials Needed**

- 50/50 Mix isopropyl alcohol/water
- Scratch resistant cloth
- 1500 watt hair dryer
(If necessary, **DO NOT use heat gun)*

2. **Installation Preparation**

- Pop off the existing OE plastic door sill piece.
- Apply alcohol and water cleaning mixture to a scratch resistant cloth. Do not apply cleaning mixture directly to vehicle surfaces.
- Clean installation surface area thoroughly and wipe dry immediately with a new clean cloth.
- Ensure parts AND vehicle surface are between 70°F and 110°F at time of installation.
**(If necessary a hairdryer may be used to reach desired temperature.)*

3. **Installation**

- Before peeling off the adhesive liner, dry fit parts on installation surface to check for proper fit and placement.
- For the top piece, peel down the top inch of the adhesive liner and align around the cutouts and gradually peel back and work down as seen in **figure 1**.
- For the bottom piece, align the **top** corner that has the sharpest radius towards the engine. Peel down the top inch of the adhesive liner and align the side edges up to the top piece installed and gradually peel back and work down as seen in **figure 2**.
- Snap the OE plastic door sill piece back in place as seen in **figure 3**.

