

Installation and Care Instructions

Tundra Mud Flaps(Rear)

Please read all instructions before installation.

1. **Tools and Materials Needed**

- 3/8" Socket Wrench
- 10mm Socket Wrench(For Factory Screws)
- 4 - 1inch Screw(Included)

2. **Installation Preparation**

- Remove factory screws. (See **Figure 1** for location)

3. **Installation**

- Using the existing 2 factory screws and 2 of the included screws, line up the mud flap and tighten each screw so it's snug, be careful not to over tighten - **Repeat steps for other side.** (See **Figure 2** for location)

Remove Factory
Screws as shown
here:



Use Included
Screws as
shown here:

