

# Installation and Care Instructions

## Tundra Mud Flaps(Front)

Please read all instructions before installation.

### 1. **Tools and Materials Needed**

- 5/16" Socket Wrench
- 10mm Socket Wrench(For Factory screws)
- 2 - 2inch screws(Included)
- 4 - Spacers(Included)

### 2. **Installation Preparation**

- Remove factory screws, see Figure 1 for location.

Remove Factory  
Screws as shown  
here:



**Figure 1**

### 3. **Installation**

- Attach the Long Screw with 2 spacers(Included), as seen in Figure 2 **\*\*Do not over tighten\*\***
- Attach the remaining 2 factory screws, as seen in Figure 3 **\*\*Do not over tighten\*\***
- Tighten each screw so it's snug, be careful not to over tighten - **Repeat steps for other side.**

Attach Long Screw  
and 2 spacers as  
shown here:



**Figure 2**



**Figure 3**