

Installation and Care Instructions

Tundra Mud Flaps(Rear)

Please read all instructions before installation.

1. **Tools and Materials Needed**

- 10mm Socket Wrench(For Factory Screws)

2. **Installation Preparation**

- Remove factory screws, see Figure 1 for location

3. **Installation**

- Using the existing 5 factory screws, Tighten each screw so it's snug, be careful not to over tighten - Repeat steps for other side.

Remove Factory
Screws as shown
here:



Figure 1



Figure 2