



beautiful,
durable,
brilliant,
resilient.

Commercial Resilient Vinyl Care & Maintenance Guidelines

MAINTENANCE

When performing any wet maintenance, always use wet floor signs.

Newly Installed Floor Care

- a. Keep all foot traffic off the new floor for 12 hours. When using S150 Spray Adhesive, material can be walked on immediately. b. Keep furniture, fixtures and rolling traffic off the new floor for 36 hours when using Shaw 4100; when using S150 Spray, avoid rolling traffic for 24 hours.
- c. Remove adhesive residue with a clean white cloth dampened with mineral spirits.
- d. Use 1/4" or thicker plywood to protect the surface when moving heavy objects across the new floor. e. Lightly damp mop the floor as needed.
- f. Wait 4 days before wet washing and scrubbing the new floor.

Initial Maintenance

- a. Sweep, vacuum or dust mop to remove dirt and grit.
- b. If needed, add neutral cleaner to cool water following the manufacturer's instructions. c. Scrub with a low-rpm machine or auto scrubber. Use a red pad or brush.
- d. Never use brown or black pads (too aggressive and can damage the product)
- e. Remove the cleaning solution with a wet-dry vacuum or auto scrubber until the floor is dry. f. Rinse the floor with clean water. Repeat the rinse process if necessary to remove all haze.

Routine Maintenance

- a. Sweep, vacuum or dust mop to remove dirt and grit.
- b. Add neutral pH cleaner to cool water following the manufacturer's instructions.
- c. As needed, scrub with a low-rpm machine or auto scrubber to retain appearance. Use a red (light scrubbing) pad and neutral cleaner following the manufacturer's instructions.

Preventative Floor Care

- a. Recommend 10' to 12' of walk off matting to capture soil load. Use walk-off mats that are as wide as the doorway and long enough for soil load and weather conditions. b. Use mats with a non-staining backing.
- c. Floor protectors should be used on all furniture legs. Recommend heavy duty, felt furniture leg protectors.
- d. The surface area of the floor protectors should be no less than 1" in diameter.
- e. Keep direct sunlight off of the floor with window protection, such as blinds or UV tinting.

For a list of recommended maintenance products contact Shaw Inforum: 1-877-502-7429

LIMITED WARRANTY

Shaw warrants its sheet, tile and welding rods to be free from manufacturing defects for ten years from the date of purchase. Shaw does not warrant installers' workmanship. Workmanship errors should be addressed to the contractor who installed the floor. Your Shaw commercial floor should be professionally installed by contractors who have demonstrated expertise in installing commercial floors

For complete warranty information, limitations and terms and conditions please call Shaw Inforum: 1-877-502-7429.

shawfloors.com