

SELF IGNITION!!

IMPORTANT: DISPOSE OF OILY RAGS PROPERLY

After use, all oil soaked rags, cloths, and pads must be soaked in water and properly discarded in order to prevent self ignition. After removal from the job site, oily rags may be laid flat in a safe place to dry, such as on a concrete driveway. Once dry, rags, cloths, and pads are safe to discard.

DETERMINE THE METHOD OF REPAIR

There are three levels of damage to be repaired:

1. A light stain that does not penetrate to the wood.
2. A light surface scratch that shows in the finish, but does not penetrate to raw wood.
3. A penetrating stain or a deep gouge that penetrates the wood and has either stained the wood or removed the finish and exposed the raw wood.

TO REPAIR A LIGHT STAIN

For a light stain, clean the effected area with diluted oil refresher (20 parts lukewarm water to 1 part oil refresher) and scrub the stain with a soft scouring pad (not steel wool) or a nylon brush. Allow the spot to air dry for one (1) hour. Re-apply a small amount of touch up oil onto the spot, let it soak on the spot, and remove excess oil after 20-30 minutes. Buff dry with a clean, dry cloth to blend the repaired area with the sheen level of the surrounding floor.

TO REPAIR A LIGHT SURFACE SCRATCH

For a light surface scratch, clean the effected area with diluted oil refresher (20 parts lukewarm water to 1 part oil refresher) and scrub the effected area with a soft scouring pad (not steel wool) or a nylon brush. Allow the spot to air dry for one (1) hour. Apply a small amount of touch up oil and allow to soak for 20-30 minutes. Buff dry with a clean, dry cloth to blend the repaired area with the color and sheen of the surrounding floor.

TO REPAIR A PENETRATING STAIN OR DEEP GOUGE

For a penetrating stain or a deep gouge, first sand the effected area with 120 grit sandpaper to remove the stain and/or blend and smooth the edges of the gouge, if necessary. Clean the effected area with diluted oil refresher (20 parts lukewarm water to 1 part oil refresher) and scrub the effected area with a soft scouring pad (not steel wool) or a nylon brush. Allow the spot to air dry for one (1) hour. Apply the touch up oil and allow to soak for 20-30 minutes. Remove excess oil and buff dry with a clean, dry cloth to blend the repaired area with color of the surrounding floor. Allow to dry for several hours or overnight, then apply a light coat of clear oil and allow to soak for 20-30 minutes. Remove excess oil and buff dry with a clean cloth to blend the repaired area with the sheen of the surrounding floor.