Self-Adhesive Surface Thermocouple *Operating Instructions and Description*

- Remove Oils Dirt from Surface to be Measured
- Peel off Protective Clear Tape and Press Sensor to Surface
- Connect Lead Wires or Connector to Instrumentation

Expose the Adhesive by Peeling Off the Clear Plastic Tape

Peel Clear Layer Up and Away from Wire and Adhesive Patch Place Adhesive Side on Surface Press Sensor Down on Surface

Fast Response Flat Thermocouple Weld Junction

ANSI Color Coded ^{Tap} 30 Gage Solid PFA Insulated Thermocouple Lead Wire .022" x .038"

1" Long x .750" Wide x .012 Thick Polyimide and Fiberglass Tape with Silicone Adhesive

