

Lathe Guards

Sizing Guide for "Guard Width"

Most ATS lathe guards are custom, allowing you to select the guard width. This can depend on the size of the lathe, the length of part being turned, or other requirements.

Refer to the photo on the right for "guard width". Common sizes are 18, 20, 24 and 30"



Here is one way to select the guard width:

1. Move the carriage so the cutter is all the way up to the chuck as shown below.
2. Measure from the headstock surface to the compound handle as shown.

This machine could use a 20 - 24" "Wide" Guard

