



1. **Remove wire retention clip** from strut and disconnect gas strut at the front only. Let the gas strut hang down out of the way.
2. Remove the (3) M8 bolts by using a 5mm allen wrench.
3. Remove the right side guard frame
4. Slide the lexan out of the channel

Installation is the reverse of removal. Make sure the rubber gasket/ glazing is properly seated in the grooves before re-attaching frame. A rubber mallet may aid in seating in channel.

## Cleaning

**When cleaning the lexan, use a mild soap or windex. Be sure to use plenty of solution and a clean, damp rag to avoid scratching.**