

Plug-N-Play Installation Instructions

Honda GoldWing GL1800

1. Remove left glovebox
2. Locate the back of the fog light switch and follow the wire back to the second connector
3. Unclip the connector and verify that there are four pins
4. Clip the Flash To Open Plug-N-Play connector in line with the wire harness
5. Clip the pigtail to the Flash To Open transmitter
6. Secure transmitter in place with the included zip tie

Harley-Davidson

1. Access the back of the headlight through the fairing or by removing it
2. Unplug the wire harness connector
3. Plug the Flash To Open Plug-N-Play connector to the back of the headlight and the wire harness
4. Clip the pigtail to the Flash To Open transmitter
5. Secure transmitter in place with the included zip tie

H4 Headlights

1. Access the back of the headlight through the fairing or by removing it
2. Unplug the wire harness connector
3. Plug the Flash To Open Plug-N-Play connector to the back of the headlight and the wire harness
4. Clip the pigtail to the Flash To Open transmitter
5. Secure transmitter in place with the included zip tie