









A hex key is included with the accessory kit to complete installation.
To install the headboard bracket, place the base on it's side.

HEADBOARD BRACKET COMPONENTS						
Headboard Bracket (2)	T-Bracket (2)	Long Bolts (8)	Short Bolts (6)	Wingnuts (2)	Washers (2)	Hex Key (1)
						



1. Attach the Headboard Bracket.

- Align the hole in the bracket to the brass sleeve into which the leg threads. Hold the bracket in place and screw the leg into the base until it is snug. **DO NOT OVERTIGHTEN.** Too much force may cause the leg to spin freely.
- Align the tab with the hole in the frame (located towards the foot of the base) and use a short bolt, washer and wingnut to secure the bracket. Make sure the bolt is tight.



2. Attach the T-Bracket.

- Measure the distance between the mounting holes on the headboard and install the T-Bracket to accommodate the headboard.
- To install the T-Bracket, slide the T-Bracket through the end of the headboard bracket. Align the flat side of the T-Bracket plate to the mounting holes on the headboard.
- Secure T-Bracket in place by inserting two short screws through top of bracket. Use hex key to tighten screws.



3. Connect your Headboard

Connect your headboard to the attachment plate using the remaining long screws or hardware that came with your headboard. The heads of the bolts will face outward. Use hex key to tighten bolts.

