# INSTRUCTION SHEET



-J01183

Kit Numbers 91306-97Y, 91308-97Y, 91302-97Y, 91307-97Y

REV. 12-8-2000

## TAIL PAK KITS

### General

The following Tail Paks fit 1997 and later M2 models:

M2 Small Tail Pak kit 91306-97Y S3 Small Tail Pak kit 91308-97Y M2 Large Tail Pak kit 91302-97Y S3 Large Tail Pak kit 91307-97Y

### NOTE

To fit M2 Small and Large Tail Paks to Blast and X1 models without saddlebags, the following mounting harness is required:

 Model
 Part No.

 Blast
 91021-01Y

 X1
 91052-01Y

Kit contents:

1 Tail Pak 1 Raincover

1 Mounting Harness

### Installation

## Installation of Tail Pak without saddlebags

- Remove Seat
- Place the grommet of the tail pak mounting harness over the seat retaining bolt so that the longer straps are to the rear of the motorcycle. Allow the straps to drape over the sides.
- 3. Replace the seat and tighten the bolt.
- Place the tail pak on the rear of the seat and fasten all four buckles. Tighten by pulling on the straps, tuck excess webbing under the tail pak.

#### CAUTION

Do not ride with the pak removed and the mounting harness installed. The straps and buckles could cause damage to your motorcycle's body work.

#### Installation of Tail Pak on M2 with saddlebags

- Pull the mounting straps from the cutaways on the top of the saddlebags.
- Place the tail pak on the rear of the seat and fasten all four buckles. Tighten by pulling on the straps.
- 3. Tuck excess webbing into the cutaways on the saddlebag.

#### Installation of Tail Pak on S3 Models

- Remove seat.
- Place straps under the helmet holder so that the 3/4 in. strap is facing towards the bodywork. Allow straps and buckles to drape over the sides.
- 3. Replace the seat.
- Place the tail pak on the seat and fasten all four buckles. Tighten by pulling on straps. Tuck excess webbing under the tail pak.