

P35i Service Rail Kit - Installation Instructions

Part #1-00-774125

HARMAN®

BUILT TO A STANDARD, NOT A PRICE

Kit Contents:

- (1) Scissor Jack w/Adjustment Bolt
- (2) Service Rails
- (8) 1/4-20 x 5/8 - Rail Bolts
- (2) 1/4-20 x 1-1/2 - Wingscrew w/collar
- (2) 1/4-20 Wing Nut

Tools Needed:

- Gloves
- 3/8" Wrench
- Screw Gun with 3/4" socket or Ratchet Wrench

Install the service rails onto the scissor jack by lining up the holes from the service rails to the holes in scissor jack and install (2) wingscrews.

Slide the service rails into the unit, install and tighten the (8) 1/4-20 x 3/8" rail bolts.

For height adjustment of the scissor jack the use of a screw gun and socket (3/4") or ratchet wrench are the easiest options.

Note: Flange bolts have locking nuts on them and no longer need to be tightened. All adjustments are now done with the adjustment bolt.

