

DirecLink OEM Wiring Harness Guide

2/27/2018

Part Number	Make	Model	Year
RV 81A-C-10-15P	Chevy	Silverado Classic(All Styles)	2007
		Silverado (All Styles)	2003-2006
		Avalanche(All Styles)	2003-2006
		Suburban(All Styles)	2003-2006
		Tahoe(All Styles)	2003-2006
	GMC	Sierra Classic(All Stlyes)	2007
		Sierra (All Styles)	2003-2006
		Yukon/Yukon XL/Denali	2003-2006
	Hummer	H2, including SUT	2003-2007
	Cadillac	Escalade (All Styles)	2003-2006
RV 81A-C-10-20P	Dodge	Ram Pickups (All Styles)	1995-2009
		Ram Dakota w/factory tow	2010-2011
		Dakota Pickups w/OEM tow	1997-2011
		Durango w/OEM tow	1998-2009
	Chrysler	Aspen w/OEM tow	2007-2009
RV 81A-C-10-21P	Dodge	Ram Pickups (All Styles)	2010-2012
		Ram 1500 (All Styles)	2010-2012
		Ram 2500 (All Styles)	2010-2012
		Ram 3500 (All Styles)	2010-2012
RV 81A-C-10-25P	Chevy	Silverado	1999-2002
		Silverado HD (All Styles)	2001-2002
		Avalanche (All Styles)	2002
		Suburban(All Styles)	2000-2002
		Tahoe(Excluding Limited or Z71)(All style)	2000-2002
		Tahoe(All Styles)	2001-2002
	GMC	Sierra(All Styles)	1999-2002
		Sierra HD(All Styles)	2001-2002
		Yukon/Yukon XL/Denali/2500 (All Styles)	2000-2002
	Cadillac	Escalade (All Styles)	2002
RV 81A-C-10-26P	GMC	Acadia w/OEM tow	2007-2017
		Acadia Limitedw/OEM tow	2017
	Saturn	Outlook w/OEM tow	2007-2010
	Buick	Enclave w/OEM tow	2008-2017
	Chevy	Traverse Limited w/OEM tow	2018
	Chevy	Traverse w/OEM tow	2009-2017
RV 81A-C-10-34P	Ford Super Duty	F250 Super Duty Pickup	2008-2016
		F350 Super Duty Pickup	2008-2016
		F450 Super Duty Pickup	2008-2016
		F350, F450, F550 Super Duty Cab and Chassis	2008-2016
		Econoline (150,250) (All Styles)	2009-2014
		Econoline (350 Super Duty) (All Styles)	2009-2014
		Econoline 350 Superduty (RV cutaway)	2009-2011

	Ford	w/ factory tow Econoline 450 Superduty (RV cutaway) w/ factory tow Expedition(All Styles)	2009-2011 2013-2014
	Lincoln	Navigator (All Styles)	2013-2014
RV 81A-C-10-35P	Ford	Econoline E150 (All Styles) Econoline E250 (All Stlyes) Econoline E350 (All Styles) Econoline E350 RV Cutaway w/OEM tow Econoline E450 Superduty, RV cutaway, w/ factory tow Econoline E450Superduty Stripped/RV Cutaway , w/factory oem Windstar w/OEM tow Bronco Expedition(All Styles) Excursion(All Styles Explorer w/OEM tow Explorer sport trac w/OEM tow Flex w/OEM tow F150 (All Styles) F150 Heritage (All Styles) F250 (All Styles) F250 Heavy Duty F250 Styleside F250 Superduty (All Styles) F350(All Styles) F350 Heavy Duty (All Styles) F350 Super Duty (All Styles) F450 Super Duty Cab and Chassis F550 Super Duty Cab and Chassis Mountaineer w/OEM	1992-2008 1992-2008 1992-2008 1992-2008 2003-2008 2000-2002 1995-2003 1994-1996 1997-2012 2000-2005 2002-2016 2007-2010 2009-2011 1994-2008 2004 1994-1996 1997 1997-1999 1999-2004 1994-1996 1997 1999-2004 1999-2004 1999-2004 2002-2010
	Mercury	LR3(All Styles)	2005-2009
	Land Rover	LR4(All Styles)	2010-2015
		Range Rover, (All Styles)	2005-2015
		Range Rover Evoque(All Styles)	2015
		Navigator (All Styles)	1998-2012
	Lincoln	Aviator w/factory tow	2003-2005
		MKT w/OEM tow	2010-2011
		Mark LT(All Styles	2006-2008
RV 81A-C-10-36P	Ford	F150 (All Styles) F250,F350,F450,F550 Superduty(All Styles) Flex Expedition (All Styles)	2009-2018 2017-2018 2012-2016 2015-2017
		MKT w/OEM tow	2012-2015
		Navigator(All Styles)	2015-2017

RV 81A-C-10-40P	Toyota	GX470(All Styles)	2003-2009
		GX460(All Styles)	2010-2015
		LX470(All Styles)	2003-2007
		LX570(All Styles)	2008-2011
		LX570(All Styles)	2013-2015
		4Runner(All Styles)	2003-2013
		LandCruiser(All Styles)	2003-2011
		LandCruiser(All Styles)	2013-2015
		Sequoia(All Styles)	2003-2017
		Tacoma (All Styles)	2007-2015
RV 81A-C-10-45P	Jeep	Grand Cherokee w/factory tow	2011-2018
	Dodge	Durango w/factory tow	2011-2018
	Chrysler	Pacifica w/ factory tow	2017
RV 81A-C-10-50P	Nissan	Armada(All Styles)	2005-2015
		Frontier(All Styles)	2005-2015
		Pathfinder	2005-2017
		Pathfinder Armada	2004
		Titan(All Styles)	2004-2017
		NV1500 (All Styles)	2013-2015
		NV2500(All Styles)	2013-2015
		NV3500 (All Styles)	2013-2015
		Xterra w/ factory tow	2005-2015
		Infiniti QX56(All Styles)	2004-2013
RV 81A-C-10-65P	Ford Super Duty	F250 Super Duty(All Styles)	2005-2007
		F350 Super Duty (All Styles)	2005-2007
		F350, F450, F550 Super Duty Cab and Chassis	2005-2007
RV 81A-C-10-16P	Cadillac	Escalade (All Styles)	2015-2016
	Chevrolet	Silverado 1500 (All Styles)	2014-2017
		Silverado 2500 HD (All Styles)	2015-2017
		Silverado 3500 HD (All Styles)	2015-2017
		Suburban (All Styles)	2015-2016
	GMC	Tahoe (All Styles)	2015-2016
		Sierra 1500 (All Styles)	2014-2017
		Sierra 2500 HD (All Styles)	2015-2017
		Sierra 3500 HD (All Styles)	2015-2017
		Yukon (All Styles)	2015-2016
RV 81A-C-10-23P	Dodge	Ram 1500 (All Styles)	2013-2014.
		Ram 2500 (All Styles)	2013-2014.
		Ram 3500 (All Styles)	2013-2014.
RV-81A-C-10-17P	Toyota	Tacoma (All Styles)	2016-2017
		Tundra(All Styles)	2016-2017