IRON ON WOVEN LABELS

APPLICATION INSTRUCTION

- Our iron on woven labels can be applied using a standard domestic iron or a heat press.
- For best results use a thin piece of fabric or gauze in between the label and the iron.
- DO NOT wash the garment/item for at least 48 hrs after applying the label to ensure proper adhesion.
- DO NOT wash the garment/item at a temperature of more than 45°
- <u>DO NOT</u> iron with steam.
- For proper adhesion the temperature of the iron must be no lower than 140° and no higher than 185°. Exact temperature will be determined by fabric of garment/item it is being applied to.
- For best results hold the label in place using the iron/press for 15 seconds. If needed and the fabric can withstand the heat it can be held for longer.

We believe the above information to be accurate and reliable to the best of our knowledge. It remains the responsibility of the user to determine the suitability of the fabric the label is being adhered to withstand the required heat.