



DOOR HANDLE INSTALL

List of tools required to complete this installation that are not included in this kit:

Phillips Screw Driver & 1/8" Hex Wrench

STEP 1: Remove the inner handle by using a 1/8" hex wrench and loosening the set screw located on the shaft of the handle.

STEP 2: Next, on the exterior of the door, turn the handle perpendicular to the two screws to allow for easy access for removal of the screws with a Phillips screw driver.

STEP 3: Remove the screws from the exterior door handle with your Phillips screw driver.

STEP 4: Install your new handle to the exterior of the door. Make sure to add the provided spacer to the exterior handle before sliding your new retro-fit exterior handle through the door handle hole of the blind.

STEP 5: Re-install the (2) screws by hand-tightening them to the blind with your screwdriver. (Note: You may have to turn the handle perpendicular to allow for easy access to the screw holes before securing the screws. If your handle is locked, unlock it to allow for full range of motion of the handle.)

STEP 6: Re-install the interior handle by sliding the handle down the exterior door handle shaft, and then carefully hand tightening the interior handle's set screw with your 1/8" hex wrench until snug.

You now have fully replaced the Door Handle in your Redneck Fiberglass Blind!

**To learn more about this product and the full line of products Redneck Blinds has to offer...
Visit redneckblinds.com for more details.**