



WINDOW GASKET MANUAL

Here is a list of tools required to complete this installation that are not included in this kit:
Black Window Adhesive & Utility Knife

STEP 1: Open the window to the fully open position and secure the window in place with either the blind's built in spring clip or window holder.

(Note: When replacing the gasket on horizontal windows, the window needs to be in the closed position to access the top weather-strip and opened to access the remaining weather-strips.)

STEP 2: Next, remove old gasket by peeling out or with a utility knife/paint scraper. Make sure to clean off any left-over debris to insure the best surface for the installation of the new gasket.

STEP 3: Install the bottom gasket first by applying a line of black weather-strip adhesive the length of the weather-strip inside the weather-strip cavity. Then carefully slide the gasket over the fiberglass edge of the blind and slowly depress the gasket down on the fiberglass edge from the center outward until it sits completely snug on the blind.

STEP 4: Finally, peel & stick the sides and top pieces in place making sure cut back the excess weather-stripping in the process with your utility knife. Add a little black weather-strip adhesive to the adjoining corners of the weather stripping to ensure there is no moisture seepage in these areas.

STEP 5: Repeat these steps for any other windows that need window gaskets replaced.

You now have fully replaced a Window Gasket in your Redneck Fiberglass Blind!

**To learn more about this product and the full line of products Redneck Blinds has to offer...
Visit redneckblinds.com for more details.**