### **Construction Solutions**

7801 E. Gray Rd. Suite 110 Scottsdale, AZ 85260

260 Fax: (480) 346-8250

Ph: (480)346-8240

www.newconstructionsolutions.com

DBX1000M Recessed Vent Receptacle
Installation Guidelines &
Product Information

# **INSTALLATION INSTRUCTIONS FOR THE DBX1000M**

## 22 GAUGE METAL DRYER VENT BOX WITH MATCHING "SNAP ON" TRIM RING

The DBX 1000M is 9 ¾" X 17" and 3 ½" deep or 5" deep. The 3 ½ "deep box can be used for either 2x4 or 2x6 framing. The 5" deep box is for 2x6 framing. It is a 22 gauge metal dryer vent box with a 22 gauge "snap on trim ring". It can be installed in 16" or 24" o.c. framing. The DBX 1000M dryer vent box/ring is powder coated.

For optimum results install the DBX 1000M for up/down venting in 2"X4" or 2"X6" framed walls as follows:

#### Box Installation – 16" or 24" On-Center Spacing:

- 1. Orient box to match desired venting direction. Allow a minimum of 4" of vent pipe to extend into the box.
- 2. If gas line is to be installed, insert into knockout provided.
- 3. Slide box into position taking care to correctly align vent pipe and gas pipe (if present).
- 4. Set box so that the bottom is 2 5/8" above the floor to allow clearance for the trim ring.
- 5. Attach box directly to either framing member and use straps to secure the other side to the opposite framing member.
- 6. Screws or nails (1 1/4") in length to attach the DBX1000M Box to framing.

#### **Trim Installation Instructions:**

- 1. Trim carpenter to leave 1 ½" between inside edge of box and end of baseboard to allow trim ring clearance.
- 2. Snap trim ring into opening, No Caulking Required.
- 3. Trim Ring is powder coated, no finishing required.
- 4. Trim Ring accommodates ½" or 5/8" drywall.