SOUTHWEST BOOT CO.

760 West California Ave. unit A Giendale, Ca 91203 Tel:(818) 242-7050 (818) 243-2465 Fax:(818) 241-8766



- FIRST STEP: Insert lace into the bottom eyelet's from both the zipper- insert and the gusset. Draw lace through eyelet toward you (fig. "A")
- SECOND STEP: Cross right hand lace to the left hand eyelet horizontally (Fig. "A") Insert the lace down into the first eyelet from the top. (Note that the right hand lace enters down into the same eyelet that the left hand lace was drawn up from). Draw right hand lace up through second eyelet (Fig. "B"). Follow the same directions with the left hand lace. DO BOTH SIDES OF THE ZIPPER AT THE SAME TIME.
- THIRD STEP: Continue lacing the same as step #2. lacing the zipper-insert in place LOOSELY as you proceed (Fig. "C"). NOTE: In following This procedure you will likely run out of lace before you reach the top of the boot.
- FOURTH STEP: Put your foot into the boot and pull zipper up to the top. Starting at the bottom of the zipperinsert, snug up laces tight.
- FIFTH STEP: Continue lacing as before in step #2 until the next to the last eyelet.
- **SIXTH STEP:** Terminate the lacing by passing the right hand lace diagonally crossing underneath the zipper-insert and drawing it up through the last eyelet (Fig. "D"). Do the same with the left hand lace. Adjust laces for proper tension with your foot in the boot, zipper closed, both sides laced. When adjustment is complete tie a double bow knot. After a few wearing re-tighten laces from the bottom up. You may want to repeat this procedure two or three times. When the break-in is complete tie off laces in a hard square knot and cut off excess lace tips.