



# Hi-Lux, Inc.

3135 Kashiwa Street, Torrance, CA 90505, Tel: (310) 257-8142, Fax: (310) 257-8096

## W1885MT INSTALLTION INSTRUCTION



**Front Mount**



**Rear Mount**



**Dovetail Block**



You need to put the 3/8" dovetail block into the dovetail cut first. Tighten the center screw on the dovetail block and jam the block into the dovetail cut. Then you need to put the front Mount on top of the dovetail block and tighten the screws into the dovetail block from both side of the front mount as the above picture showed. Install the rear mount to position as the above picture indicated. Two 6-48 screws are needed for the rear mount. If you have any questions about this product, please feel free to contact us at the toll free no. 1-888-HI-LUX-12 (445-8912) or send us an e-mail to [techsupport@hi-luxoptics.com](mailto:techsupport@hi-luxoptics.com).

### **WARNING:**

**You must install the mount securely before you shoot the rifle. This should be done by a competent gunsmith.**