



TOOLS AND SUPPLIES YOU MAY NEED TO INSTALL YOUR SHOWER

- 1/2" CEMENT BOARD (for some installs you may need 6 mil. water/vapor barrier plastic sheeting)
- 100% RTV SILICONE WITH CAULKING GUN
- GROUT (powdered non-sanded with additive for adhesion or pre-mixed non-sanded)
- PENCIL OR MARKER
- HAMMER
- DRILL WITH 3/16" & 1/2" DRILL BITS
- LEVEL
- PHILLIPS HEAD SCREWDRIVER or PHILLIPS DRILL BIT
- HANDHELD MAKITA GRINDER WITH 4" TILE BLADES (Diamond Tip recommended)
- UTILITY KNIFE
- 3/4" HOLE SAW
- MEASURING TAPE
- ADJUSTABLE WRENCH
- SPONGE
- GROUT FLOAT & BUCKET
- 1/8" PLASTIC TILE SPACERS
- SHEET ROCK SCREWS
- NAILS
- 3" SCREWS
- WOOD SHIMS
- 60 GRIT SANDPAPER
- DROP CLOTH OR PLASTIC SHEETING
- 3" SCREWS
- CIRCULAR SAW
- BRACES TO SECURE WALL PANELS
- CLEAN CLOTHS