

# 2011-2016 SUPER DUTY REVERSE

## STEP 1

Remove the two 8mm size bolts from the assembly.



## STEP 2

Pull the taillight assembly away from the truck to expose the reverse light socket.



**Reverse bulb socket**

## STEP 3

Turn the socket counterclockwise to expose the bulb, remove the stock bulb (be careful as this bulb may be hot) Then insert the MKII Cree Reverse bulb into the socket (test the bulb and if it does not light rotate it 180 degrees then reinsert it.





## STEP 4

Repeat steps 1-3 on the other side of the truck.

## STEP 5

Reinsert the socket into the taillight assembly and lock it in using a clockwise turn. Then insert the taillight assembly back into place and reinstall the bolts.



Text for support: 706-214-2618

Visit our site to chat: [www.F150LEDs.com](http://www.F150LEDs.com)  
or email [CustomerSupport@F150LEDs.com](mailto:CustomerSupport@F150LEDs.com)

