

# 2011-2016 SUPER DUTY TAIL LIGHT

## STEP 1

Remove the two 8mm size bolts from the assembly.



## STEP 2

Pull the taillight assembly away from the truck to expose the Taillight bulb.



**Taillight socket**

## STEP 3

Turn the socket counterclockwise to expose the bulb, remove the stock bulb (be careful as this bulb may be hot) Then insert the MKII Taillight bulb into the socket (test the bulb and if it does not light rotate it 180 degrees then reinsert it. If you experience hyper flashing when testing the bulb, install the included resistor units by splicing the resistors to the two outside wires of the turn signal socket using the provided connectors.





## STEP 4

Repeat steps 1-3 on the other side of the truck.

## STEP 5

Reinsert the socket into the taillight assembly and lock it in using a clockwise turn. Then insert the taillight assembly back into place and reinstall the bolts.



Text for support: 706-214-2618

Visit our site to chat: [www.F150LEDs.com](http://www.F150LEDs.com)  
or email [CustomerSupport@F150LEDs.com](mailto:CustomerSupport@F150LEDs.com)

