

STEP 1

Be sure that there is no power going to you Tag lights.

Locate tag bulb socket by looking under your bumper.







STEP 2

Twist the socket counterclockwise and pull away from the truck to expose the bulb, carefully pull the stock bulb out of the socket.









Insert the MKII tag light bulb. **Test your bulb** to ensure that it is working, if not rotate your bulb 180 degrees. Reinsert your tag light socket back into your housing using a clockwise turn to lock it into place.









Text for support: 706-214-2618 Visit our site to chat: www.F150LEDs.com or email CustomerSupport@F150LEDs.com



