



Replacement of Fenders on Segway MiniPro.

Step 1. Power Off Mini Pro

Step 2. Remove the Knee controlled bar or Handlebar

Step 3. Remove the Battery

Step 4. Remove the Axle Clamp that hold the Wheel (you can keep the wheel connected but be careful not to damage the wires)

Step 5. Remove the four fasteners that hold Fender.

To install a new Fender (both regular or Off Road) please follow Steps 5-1 in the reverse order.