## Proline Pendant Installation Instructions



HAVIT



## Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- All o-rings and seals must be in place correctly to maintain warranty
- This form may be updated at any time due to product improvements, please check online installation form for most current version.

## Steps for Installation:

- 1. Make sure that the electrical circuit is free of voltage (master switch off)
- 2. Install Suspension Kits in desired locations using appropriate screws for application.
- 3. Adjust cable length and cut off any excess.
- 4. Remove bracket from canopy by pulling gently
- 5. Install Bracket in desired location using appropriate screws for application
- 6. Slide cable through canopy
- 7. Connect the cable: Use wire with earth, connect earth first then positive and then neutral
- 8. Reattach canopy to bracket by pudhing gently until canopy clips into place.
- 9. Fitting is preset to 3000k, To change slide switch on top of fitting to desired colour temperature
- 10. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

## Must be installed by a licensed electrician

Contact Details:		Warranty Terms & Conditions*	Additional Information
143 Beauchamp Road Matraville NSW 2036 Australia	Tel: 02 9381 8300 Fax: 02 9666 8881 Email: sales@havit.com.au Web: www.havit.com.au		