



# ORACLE LIGHTING

## CHEVROLET CORVETTE C7 ILLUMINATED EMBLEM INSTALLATION GUIDE

### TOOLS NEEDED:

- FLAT SCREWDRIVER • DRILL/OR DREMEL TOOL • FISHING LINE • GOO GONE • HEAT SOURCE • T-TAPS



1

BEGIN BY REMOVING THE FACTORY BADGE. IT HELPS TO FIRST HEAT THE AREA TO SOFTEN THE FACTORY ADHESIVE. YOU CAN USE A HAIR DRYER, HEAT GUN, OR JUST PARK THE CAR IN THE SUN FOR A WHILE.



2

NOW USING A PIECE OF FISHING LINE, BEGIN AT ONE END OF THE EMBLEM AND WORK YOUR WAY TO THE OPPOSITE SIDE USING A BACK AND FORTH MOTION, UNTIL BADGE IS REMOVED. USE GOO-GONE TO REMOVE EXCESS RESIDUE.



3

TO ACCESS THE REAR OF THE VEHICLE, YOU WILL NEED TO REMOVE THE REAR INTERIOR COVER PIECE. THIS PIECE IS HELD IN BY A FEW CLIPS. PULL UP ON THE COVER TO RELEASE. YOU WILL NOW HAVE ACCESS TO REAR OF THE VEHICLE.

4A

YOU WILL NOW DRILL A HOLE IN THE REAR BUMPER TO ROUTE THE WIRES INTO THE TRUNK. THE REAR BUMPER IS PULLED BACK FOR EASIER ACCESS.



4B

CLEAN OF THE SURFACE WITH AN ALCOHOL SWAB. REMOVE THE BACKING FROM THE ADHESIVE, AND PLACE THE EMBLEM IN POSITION. HOLD FOR 10-15 SECONDS TO INSURE A PROPER BOND.



5

LOCATE THE PASSENGER SIDE REAR LIGHTING PLUG. THIS IS WHERE YOU WILL USE T-TAPS TO TAP INTO THE VEHICLE'S EXISTING WIRING. ON YOUR EMBLEM, THE RED WIRE WILL BE YOUR (+) AND THE BLACK WIRE YOUR (-)



6

NOW T-TAP THE CORRECT WIRES, YELLOW/WHITE WIRE IS THE BRAKE LIGHT WIRING, THE BROWN WIRE IS THE PARKING LIGHT WIRING. IF YOU HAVE A DUAL INTENSITY EMBLEM, YOU WILL USE BOTH PARKING AND BRAKE WIRES.

FOR TECH SUPPORT PLEASE CALL 1-800-407-5776