

# Unnie Moran

WALLPAPER

## Premium Matte Wallpaper specs and installation instructions

- completely matte finish with a soft suede-like feel, similar to watercolor paper
- FSC®-certified paper from well-managed forests
- odorless
- Carries a ASTM – E84 Class A fire certification.
- PVC-free for easier disposal

This wall paper must be applied with standard wallpaper paste.

You may be interested in more detailed information on hanging wall paper. There are many good sources of this information, including the Residential Guide on the Wallcoverings Association website at [wallcoverings.org](http://wallcoverings.org). These instructions are provided as recommendations. Your professional wallpaper installer may adjust installation methods based on your specific installation needs. If there is a defect in the product, do not cut or hang and contact us immediately. We are not responsible for installation errors or issues and will not accept any returns or claims regarding unsatisfactory installation results.

### Recommended Installation Instructions:

1. All hanging surfaces must be clean, smooth, dry, undamaged, free of mold, mildew, grease or stains. All loose paint and other wallcoverings should be removed.
2. Prepare wall with GARDZ or similar primer. Allow primer to dry fully before continuing.
3. Use a premixed clear professional grade adhesive. Roll adhesive to back of panel by hand or use a pasting machine. Do not paste wall.
4. Carefully lay ends of panel in onto itself without creasing. Adhesive side of panel should be completely stuck to itself. Allow a few minutes for booking.
5. Measure wall and panel width to determine the edge of the first panel. Use a level to ensure plum. Unfold roll and place it on the wall starting from the top.
6. Using broad smooth strokes work excess paste and trapped air from center out left and right until panel is smooth. Do not work up or down. Avoid burnishing the face of the material. Use a wallcovering brush or a plastic scraper to gently smooth the wallcovering onto the wall.
7. Repeat process with consecutive panels. Butt edges tightly at the pattern match without overlapping. Cut ceiling and floor cuts before moving to next panel.
8. Do not rub. Do not allow the adhesive to dry on surface as it may leave a white residue. Wash off excess paste from face of wallcovering as you hang it with a cellulose sponge. The cellulose sponge must be rinsed in clean water after every use. Blot dry with a clean cloth. No scrubbing, abrasive or solvent cleaners. Use seam roller to make sure all seams are bonded well.
9. After installation is complete, minor blisters like small bubbles may be present. Please allow 7 days for adhesive to fully cure. As wallpaper cures it will tighten like a drum and pull taught any minor blisters. Do not try to press them down with your finger. The walls and wallcovering should be monitored for potential moisture or vapor infiltration or accumulation. Any such infiltration/accumulation after installation must be promptly eliminated in order to reduce the risk of mold/mildew growth.