

Unnie Moran

WALLPAPER

Type II Terralon Commercial Wallpaper specs and installation instructions

- smooth or textured finish
- scrub and scratch resistant
- water, moisture, mold and mildew resistant
- ASTM E96 Permeability compliant
- Type II wallcovering, ASTM F793 compliant for durability characteristics
- NSF-342 - Certified for Silver compliance
- odorless and breathable
- Class A rated flame-spread performance material
- Sustainable, Includes recycled content - Minimum 31% post-consumer recycled content
- Free from phthalate and brominated flame retardants
- PVC-free for easier disposal
- earn LEED credits

This wall paper works with common primers, pastes, finishing, and installation methods. These instructions are recommendations however your installer may adjust for your specific installation as they see fit. We do not warrant these instructions and we are not responsible for installation errors or issues.

Recommended Installation Instructions:

1. All hanging surfaces MUST be clean, smooth, dry, undamaged, free of mold, mildew, grease or stains. All loose paint and other wallcoverings should be removed.
2. Prepare wall surface with a permeable, mold and mildew inhibiting wallcovering primer. Allow primer to dry fully before continuing.
3. Use a heavy-duty professional grade adhesive along with a mildew inhibitor such as Roman Eco. The adhesive should be whipped/mixed thoroughly to ensure smooth even application. Roll adhesive to back of panel by hand with paint roller, being sure to cover edges. Do not paste wall.
4. Carefully lay ends of panel in onto itself without creasing. Adhesive side of panel should be completely stuck to itself. Allow 10 minutes for booking.
5. Measure wall and panel width to determine the edge of the first panel. Use a level to ensure plumb. Unfold roll and place it on the wall starting from the top.
6. Using broad smooth strokes work excess paste and trapped air from center out left and right until panel is smooth. Do not work up or down. Avoid burnishing the face of the material. Use a wallcovering brush or a plastic scraper to gently smooth the wallcovering onto the wall.
7. Repeat process with consecutive panels. Butt edges tightly at the pattern match without overlapping. Cut ceiling and floor cuts before moving to next panel.
8. Do not rub. Do not allow the adhesive to dry on surface as it may leave a white residue. Wash off excess paste from face of wallcovering as you hang it with a cellulose sponge. The cellulose sponge must be rinsed in clean water after every use. Blot dry with a clean cloth. No scrubbing, abrasive or solvent cleaners. Use seam roller to make sure all seams are bonded well.
9. After installation is complete, minor blisters like small bubbles may be present. Please allow 7 days for adhesive to fully cure. As wallpaper cures it will tighten like a drum and pull taught any minor blisters. Do not try to press them down with your finger. The walls and wallcovering should be monitored for potential moisture or vapor infiltration or accumulation. Any such infiltration/accumulation after installation must be promptly eliminated in order to reduce the risk of mold/mildew growth.