

STEP 1

Flip badge over and peel off the back label exposing the sticky adhesive back.



STEP 2

Place badge in designated area of radiator.

