
WALL MOUNT BRACKETS



1. Attach Frame Floor Yokes to Wall Mount Brackets using 5/16" Bolts, Washers, and Nuts.
2. Locate Frame on wall and attach Wall Mount Brackets to bottom of wall using 3" Screws, securing to wood wall plate.

Note: Be sure to mount the frame as far forward from the wall as needed to allow for your mattress thickness, etc. (no less than 14" from the wall to the bolt heads on the front of the Yoke Assembly).