

49CC ATV/QUAD Instruction

Open the box, get all spares out. Bolts and nuts See pic A.



1. Install handlebar (4 bolts with brackets). See pic 1A,1B.



2. Install front wheels and tie rods. See pic 2A, 2B, 2C, 2D.

(Tip: You need a plier to hold the top, then use a drill/spanner to tighten the bottom nut.)



3. Install the front bumper and rack. See pic 3A, 3B, 3C.



4. Install the rear wheels, insert the keyway. See pic 4A, 4B, 4C, 4D.



5. Install the rear rack. Use the bolts and lock nuts. See pic 5A, 5B, 5C.



6. Install the footrests, 3 bolts and 3 nuts for each side. See pic 6A.



7. Put the rear reflector on the rear rack. See pic 7A.



8. Now the assembly is finished. See pic 8.



After that, Please check all bolts/nuts are tight. Front wheels are aligned. Front and rear brakes are working. Connect the fuel line into the carby.

Mix 91 Unlead petrol to 2-troke oil. The ratio is 25:1(1L petrol with 40ml oil), no E10 or Octane. Fill in fuel, turn on key, turn on fuel tap and the choke lever (both on the carby), then pull the start coil, the bike will be started shortly. Please turn off the choke once the engine is warmed up.

There is a throttle governor screw on the handlebar and you can limit the speed. This bike is designed to carry a kid under 45kgs. Adult will not allowed to ride it on. The clutch will be broken in minutes if an adult is riding on it.