

# B.S. National Open Mesh Floor with landing board

Arrange the panels as shown to the right. The top panel here will become the back, with two longer side panels running vertically, and the front panel above the landing board. After identifying which panel is which assembly is relatively simple. These instructions demonstrate the assembly order of the floor - **you should nail together the floor once you are happy with the assembly method.**



**Step 1**

Fix together the back and side panels. The back panel will be elevated when the floor is laid flat, to accommodate the draw.

**Step 2**

Attach the front panel with the groove facing outwards. The gap above is for the entrance block and mesh.

**Step 3**

Insert the landing board into the front grooves.

**Step 4**

Insert the mesh via the grooves. This may be a tight bit - you may find it easier to put the mesh in after Step 1.

**Step 5**

Attach the handle to the shorter side of the corex draw.

**Step 6**

Slide the draw into the rear grooves.