



INSTALLATION INSTRUCTIONS

PART LIST AND ASSEMBLY INSTRUCTIONS

Parts



H2O proof/uv protective ripstop canopy



2 fiberglass canopy poles
14.8ft. (4.5 m.)



6 aluminum stakes



4 guylines
9ft. (2.7 m.)



2 shock-corded metal support poles
6 ft. (1.8 m.)



Carry bag



1 canopy cross pole
8.4 ft. (2.6 m)



2 suction cups with hooks

Parts

possible uses



shade 76+ ft.²



shade 72+ ft.²



shade 72+ ft.²



shade 60+ ft.²



shade 76 ft.²



INSTALLATION INSTRUCTIONS

instructions



step 1.
Open carry bag, pull out contents.



step 2.
Spread canopy flat on ground with top clips facing up.



step 3.
Assemble the 2 fiberglass canopy poles and lay them across the canopy in an "x" formation.



step 4.
Using tension to bow the poles, a.)take one fiberglass canopy pole and insert the plastic capped end into one of the corner rubber sleeves. b.)next, insert the metal capped end of the canopy pole into the grommet diagonal to that rubber sleeve. Use grommet hole closest to fabric. repeat step.



step 5.
Start at one end of one of the fiberglass canopy poles and attach all clips underneath it. Next, move to second fiberglass pole and repeat step.



step 6.
Assemble canopy cross pole and flip canopy over. On the underside of the canopy insert each end of the canopy cross pole into a yellow side pocket. Then, secure cross pole to canopy with center tie.



step 7.
Choose desired position for your occasion. Ensure canopy is stable at all times by using provided suction cups, shock-corded support poles, stakes, and/or guylines. See examples on reverse side.



step 8.
After use, reverse steps and place items back into the carry bag.