

GRAND CRU 194 SERIES WALL ANCHORING INSTRUCTIONS

1. Before installing the hook, it is necessary to confirm that the top of the hook is parallel to the top of the cabinet.
2. Drill a $\phi 10 * 40$ hole on a load-bearing wall or stud and then install the matching expansion screw to fix it.
3. The 2 hooks in the box should be installed.

