How to Apply?

 Equipment: 50 ml Oxon Sure Grip Anti-Slip Solution, an alarm clock or a smartphone with Timer, a clean and dry Spraying Bottle or a small mug/container, a clean Roller or small Paintbrush, a Mop or Plastic Brush and a slightly used fiber Scrub Pad (such as Scotch Brite Scrub Pad).

Do not use a steel wool type abrasive scrub.

Essential gear for Applicator - Plastic Gloves, Eye Protection (Glasses)
and Covered Shoes

 Planning: If working alone as a Single Applicator, we recommend dividing the floor into sections of 25-30 sq. ft. to work on at a time.
 Start from the point furthest from the exit and work your way out.

Preparation:

- Clean the surface and make sure it is free from dirt or grease and Use the Scrub Pad to remove all the grime between the tiles/floor panels.
- If the floor was cleaned with a bleach, ensure that all the bleach has been washed away. Use a plastic brush or scrub pad as an additional check.
- Dry the floor thoroughly with a mop making sure it's rid of moisture.

· Steps:

- After you've prepared the floor as instructions above, please ensure you put on the basic gear
- Pour the chemical into the Spray Bottle or into a wide pan into which you can dip the Roller/Paintbrush for direct application
- 3. Spray the Chemical with one hand and spread it uniformly using the roller or paintbrush over the floor with the other. In case you don't have a spray bottle, apply directly using the Roller or Paintbrush but be careful about wastage
- 4. Ensure you keep agitating the chemical lightly with the brush every few minutes - do not let it dry or pool between the tiles for the entire period of 12-15 minutes from initial application. This is necessary for it form a strong bond with the floor as a critical action
- 5. Repeat steps for the rest of the floor sections
- Once done, wash the entire floor thoroughly with cold water lightly using the scrub pad or a brush with soft brush to remove the excess chemical

Note: Hard, dense surfaces or glazed tiles may require additional applications to produce desired level of slip resistance.

REMEMBER

- Use Oxon Sure Grip Floor Cleaner cum Booster (launching soon) regularly to keep the micro-pores free from buildup of dirt and grease once a month
 This is also necessary for the warranty to be valid
- Some patches of white residue efflorescence may appear on the floor. This is normal and usually takes a few weeks of regular cleaning and maintenance to disappear

- The cleaner the floor is kept, the more effective will be the anti-slip treatment
- Never use a mop to clean any floor treated with this solution. Instead a Brush with Plastic Bristles should be used to clean and washed off with cold water