



OG Softail 18+ Complete Headlight Conversion Kit-1.1

1. Before you start your new conversion kit installation, you will need to remove your stock complete headlight assembly. Please refer to service manual if needed. Before unplugging your stock headlight, we recommend removing your masters fuse located under the left side cover. Keep all the stock hardware, you might need some later during the installation.
2. Unpin your headlight connector inside your stock headlight bucket. Please note the wiring sequence if you don't have access to a service manual. Reassemble the connector outside the bucket. The wiring harness pre-installed in your new headlight bucket will connect directly to it. Refer to picture below. Remove your stock headlight bucket & headlight bracket from your bike.



3. With a 27/64" or 7/16" metal drill bit, drill to open up the lower headlight bracket hole located on your lower triple tree. This can be done easily using any hand held battery drill. This will allow you to use the included & more sturdy hardware.
4. Install the supplied headlight bracket kit on top of your lower triple tree. You will need to remove the small OEM dowel pin on the lower tree (if applicable). Recommended max. Torque 15 ft-lbs.
5. Install & plug your new 5.75" LED Headlight into the supplied 5.75" Headlight bucket. Install your headlight bucket onto your headlight bracket using supplied 3/8 -16 hex bolt, washers (2x) & lock nut. Recommended Torque 15 ft-lbs.
6. Plug the new Headlight 4 pin connector into the OEM Delphi connector. At this point you can re-install your master fuse on your bike.
7. Enjoy!