



# -INSTALLATION- INSTRUCTIONS



LP ADVENTURE LIFT KIT



SUBARU IMPREZA WRX 2022 +

# CONGRATULATIONS ON YOUR NEW LP AVENTURE LIFT KIT!

If you have any question or need assistance during the installation please contact our team. You can find the information on the last page.



IN  
THE  
BOX



IN THE BAGS

1



2



3



4





## NECESSARY TOOLS

1. - We recommend the use of a lift
2. - Jack stand to support the sub-frame
3. - Ratchet
4. -12mm Socket
5. -14mm Socket
6. -17mm Socket
7. -19mm Socket
8. - 22mm Socket
9. -12mm Wrench
10. - 14mm Wrench
11. -17mm Wrench
12. - Exhaust Hanger Removal Pliers
13. Pry Bar


1


## REMOVE WHEELS



2

## UN CLIP ABS SENSOR WIRE





3

UNBOLT THE ABS SENSOR BRACKET








4

## REMOVE BRAKE LINE BRACKET





5

UNBOLT KNUCKLE BOLTS



**\*\*REMEMBER TO MARK THE CAMBER BOLT BEFORE LOOSENING TO MAKE RE ASSEMBLY EASIER\*.**






6

UNBOLT SWAYBAR LINK





7

## REMOVE TOP PLATE BOLTS





8


## REMOVE SUSPENSION ASSEMBLY





9

USING THE SUPPLIED NUTS, ATTACH THE  
LIFT SPACER TO THE STRUT





USE A PRY BAR TO HELP SUPPORT THE TOP PLATE WHILE TIGHTEN THE NUTS





10

RE INSTALL THE SUSPENSION ASSEMBLY



FRONT RIGHT

FRONT LEFT



11

USE THE FACTORY NUTS TO  
FASTEN THE ASSEMBLY TO THE CAR



12

RE INSTALL THE STRUT TO THE KNUCKLE





MAKE SURE TO LINE BACK UP THE CAMBER BOLT



TIGHTEN THE BOLTS



13

RE INSTALL SWAY BAR LINK



14

RE CLIP THE ABS LINE




15

RE INSTALL ABS LINE BRACKET



16

RE INSTALL BRAKE LINE BRACKET



17

TIGHTEN TOP PLATE NUTS





18

REMOVE THE TRUNKS CARPET



19

REMOVE REAR STRUT BOLTS



20

REMOVE STRUT AND REAR KNUCKLE BOLTS  
ON BOTH SIDES







21

REMOVE THE REAR SUSPENSION ASSEMBLY



22

INSTALL REAR LIFT SPACERS



23

DISCONNECT THE CENTER PIPES EXHAUST HANGER



24

ONE AT A TIME, REMOVE THE FACTORY EXHAUST HANGERS AND REPLACE THEM WITH THE HANGERS INCLUDED IN THE KIT.  
\* LUBING THE HANGERS WILL HELP THE INSTALLATION





IF YOU HAVE THE FACTORY CATBACK, USE THE TRIANGLE HOLE.  
IF YOU HAVE AN AFTER MARKET CATBACK, YOU CAN USE THE  
BOTTOM HOLE OR THE TRIANGLE HOLE




25

REMOVE PLASTIC GAS TANK COVERS



26 REMOVE TWO BOLTS FROM THE SUB FRAME SUPPORT BAR





27

USING A JACK, SUPPORT THE DIFFERENTIAL



28

REMOVE THE REAR SUB FRAME BOLTS



29

TEMPORARILY INSTALL THE INCLUDED SUB FRAME BOLTS



THEY WILL HELP KEEP EVERYTHING ALIGNED  
DURING THE INSTALLATION



30

REMOVE THE FRONT REAR SUB FRAME BOLTS  
AND BRACKET




31

INSTALL INCLUDED BRACKET SPACER



32

SLOWLY LOWER DOWN THE SUB FRAME. LOWER IT JUST ENOUGH TO GET THE SPACERS IN.



33

REMOVE THE BOLTS THAT WERE PUT IN TEMPORARILY AND SLIDE IN THE LIFT SPACERS, THEN PUT THE BOLTS BACK IN.



INSTALL THE FRONT SUB FRAME SPACERS AND BOLTS



34

RAISE THE SUB FRAME BACK UP



35

TIGHTEN THE SUB FRAME BOLTS



36

TIGHTEN THE SUB FRAME BRACKET BOLTS



37

INSTALL THE HANDBRAKE CABLE BRACKET SPACER







38

DOUBLE CHECK THAT EVERYTHING IS TIGHT



39

RE ATTACH CENTER PIPE EXHAUST HANGER



40

LOOSEN BUT DO NOT REMOVE SUSPENSION ARM BOLT



41

RAISE THE REAR SUSPENSION ASSEMBLY INTO PLACE



42

RE INSTALL SUSPENSION BOLT



43

USING THE HELP OF A JACK, RAISE THE  
SUSPENSION ARM UP



44

RE INSTALL KNUCKLE BOLTS



45

RE INSTALL STRUT AND KNUCKLE NUTS




46

WHEN BOTH SIDES ARE INSTALLED,  
TIGHTEN EVERYTHING UP



47

TIGHTEN SUSPENSION ARM BOLT BACK UP



48

RE INSTALL GAS TANK PLASTICS



YOU WILL NOT NEED TO PUT BACK THIS MOUNTING PIN



49

REMOVE THE REAR BRAKE LINE BRACKET BOLT TO INSTALL THE BRACKET EXTENSION








50

ATTACH THE FACTORY BRACKET TO THE EXTENSION



51

## RE INSTALL REAR STRUT BOLTS



52

RE INSTALL TRUNKS INTERIOR



53

RE INSTALL WHEELS



INSTALLATION COMPLETE!



▼  
**NOTES:**

**\*\*Tighten all the bolts to the manufacturer's specifications with a Torque Wrench\*\***

-----  
**Double check your work.  
Reinstall the wheels and be sure to tighten  
the nuts with a torque wrench.**

-----  
**Wheel alignment is required after installation.**

-----  
**Products warnings:  
<https://lpaventure.com/pages/products-warnings>**

-----  
**Limited product warranty:  
<https://lpaventure.com/pages/limited-prod->**



**You have completed the installation.  
Thank you for your interest  
in our products.**

**For all requests, information or  
assistance: Contact our team  
by phone at  
**1 (866) 562-1316****

**We are available Monday to Friday  
Between 8AM and 5PM (EST).**

**Or by email at :  
**SALES@LPAVENTURE.COM**  
**WWW.LPAVENTURE.COM****

**NOW, ENJOY THE RIDE!**