

ClearSonic AmpPac20 & 21 Assembly Instructions

Parts Included: AmpPac20 - A1824x6, (6)S2216 AmpPac21 - A1824x6, (6)S2216, S2233



1. Stand acrylic panels up in a zigzag formation. Peel off paper masking. *Note: this product is NOT returnable once the paper masking has been removed.*



2. Set acrylic panels around your amplifier in the shape of a hexagon so that the two edge panels meet each other in the back.



3. Place four (4) pieces of included Velcro on each S2216 SORBER baffle about 1 inch from each corner. Once the Velcro is placed, peel the masking off to expose adhesive backing.



4. Place each S2216 SORBER baffle in position on the acrylic shield (1 baffle per panel). Apply pressure from both sides to get Velcro to stick. Have someone help you if you're having trouble. Once all the SORBER baffles are in place your AmpPac20 is ready to rock!

Additional step for AmpPac21:



5. Set larger S2233 SORBER baffle on top. There should be small gaps in front and back to promote air circulation.

Questions? Please call 1-800-888-6360

(CLEARSONIC)
manufacturing inc.
www.clearsonic.com