

ClearSonic GoboPac 40 Instructions

Parts Included: (1) A2448x2, (2) S2233, (8) Velcro pcs

1. Remove paper masking from A2448x2 ClearSonic Panel
2. Put S2233 SORBER baffles in position and attach velcro approximately 3" in from each corner (see picture). Allow velcro to set up overnight to ensure a more permanent bond.
3. Attach S2233 SORBER baffles.

Additional Clear Panels and SORBER baffles can be added to create a complete enclosure if more isolation is needed.

www.clearsonic.com
1-800-888-6360

