

# ClearSonic GoboPac 50 Instructions

*Parts Included:*(1) A2466x2, (2) S2233, (2) S2216, (16) Velcro pcs

1. Remove paper masking from A2466x2 ClearSonic Panel
2. Place S2233 SORBER baffles in position and attach Velcro to ClearSonic panel approximately 3" in from each corner. (see picture)  
S2216 SORBER baffles can be placed directly above S2233s or at microphone height to reduce reflection. Allow SORBER to set-up overnight to ensure a more permanent bond.
3. Attach SORBER baffles.

Additional clear panels and SORBER baffles can be added to create a complete enclosure if more isolation is needed.

[www.clearsonic.com](http://www.clearsonic.com) \* 1.800.888.6360

