

ClearSonic GoboPac 70 Instructions

Parts Included:

(1)A2466x2, (1)AX2418x2, (2)S2233, (2)S2224, (2)S2216, (24)Velcro pcs

1. Remove paper masking from A2466x2 ClearSonic Panel.
2. Attach AX2418x2 Height extenders to the top of A2466x2.
3. Place S2233 SORBER baffles in position & attach Velcro to ClearSonic panel approx. 3" in from each corner. (see picture)
4. S2224 SORBER baffles attach directly above S3s.
5. S2216 baffles can be placed above S2224s or attached to the AX2418 height extenders as shown. Allow SORBER to set-up overnight to ensure a more permanent bond.

Additional clear panels and SORBER baffles can be added to create a complete enclosure if more isolation is needed.

www.clearsonic.com * 1.800.888.6360

