

MiniMega Assembly Instructions

Tools needed: rubbing alcohol, rubber mallet, and tall assistant

Minimega Checklist:

- (1) A2466x6, (1) A2466x5, (1)AX2412x6, (1)AX2412x5, (25) S2224
- (1) S2466, (1) S1266, (2) ST2466, (1) Fan
- (12) Sections of H-Channel
- (1) Section of Base Channel
- (2) Support Bars

1. Inspect shipping cartons. If damaged is suspected, take pictures of damaged boxes.
2. Open all boxes and check for damage. Call your ClearSonic dealer immediately if you have any damaged or missing items.
3. Stand up the main 5.5' tall panel shield systems in zigzag formation with the base channel on the bottom.



4. Peel masking off panels. **(Once masking is removed panels can not be returned. Test your MegaPac with masking first if you are not sure.)** Using gloves to handle acrylic panels will help keep them free of finger prints during assembly.

5. Install H-channels on top of 5.5' tall shields. Outside edge of H-channel should line up with outside edge of shield below. Lubricate the top of the panels with rubbing alcohol (or other quick-drying alcohol solution) to aid installation.



6. Note the number of panels and hinge configuration of each shield system. Be sure the number of panels matches and that everything will fold correctly once installed. Have your assistant “feed” the folded AX panels one at a time while you place them into position atop the larger shields. Make sure the edges line up. Don’t seat the AX panels completely until all are in place. Tap the top of AX panels with a rubber mallet to seat completely into H-channel on both panel systems.