

12. The extra 'H' channel provided with your MegaPac will help keep the lid from obstructing the door panel when entering and exiting. Place this on top of the AX panel next to your door.



13. Adjust both Lid support bars to the width of the font panels. Rest one support bar on top with the J-hooks at least 4-inches from the edge of the end panels. Place the other bar about a foot in front of the first bar. Do not extend the bar beyond the red limit mark.





14. Lay the rectangular 2' wide S2466 on top (about six inches from the center of the front panels) with at least a one inch over-hang in front. The Lid sections will reston the support bars in back. Place the 1' wide S1266 right next to it with same over-hang. Complete the lid by placing the ST2466 trapezoid sections on each side. You may have to make adjustments to the panels and/or lid in order to achieve maximum coverage.

- 15. Place Velcro on all four corners of the S2224 and S2216 baffles about 1-inch from the edge. Peel off the paper to expose the adhesive.
- 16. Place the S2224 and S2216 baffles in position on the shields. When attaching SORBER baffles to your door panel, raise the bottom S2224 approximately ½ inch off the ground so it does not drag. It works best to have an assistant apply pressure from the opposite side while pressing on the baffle corners to make sure the Velcro sticks securely.
- 17. Clip the fan to the back of the S2466 or on one of the support bars to aid in air exchange.
- 18. Enjoy your MiniMega!

