

ClearSonic S2216/S2224/S2233 Instruction Sheet

1. Remove your S2216/S2224/S2233 baffles from the box and inspect for damage. Please contact your dealer to report any damaged or missing items.
2. Apply (4) of the included Velcro strips to each corner of your S2216/S2224/S2233 (see Figure 1). Peel off backing on Velcro to expose adhesive.
3. Place baffle at desired location for acoustic treatment, applying pressure on the corners (see Figure 2). For best results with an acrylic panel, it helps to have someone apply pressure from the other side of the panel while you press.
4. Remove the baffle, leaving Velcro attached to surface being treated. Press on Velcro tabs to ensure attachment (see Figure 3). Reattach your baffle to the Velcro, twisting it gently to aid attachment to Velcro.



Figure 1



Figure 2



Figure 3