

ClearSonic SKT Sorber Kick Tunnel Assembly Instructions

Pieces: (3) S2233, (1) S2224, (6) 6" pieces of Velcro

- 1) Place your kick drum mic on the floor about 3' out, facing your kick drum.
- 2) Position the S2233s and S2224s into a rectangle around it so the open end is touching the rim of your kickdrum. (It's easiest to have someone assist you with this).
- 3) Use the included velcro pieces to connect everything together. You're now ready to record cleaner, bassier kick drum tracks!



www.clearsonic.com 1.800.888.6360