

ClearSonic GoboPac 20 Instructions

Parts Included: (1)A1824x2, (2)S2216, (8) Velcro pcs

1. Remove paper masking from A1824x2 ClearSonic Panel.
2. Attach Velcro approximately 3" from the corner of each panel in the A1824x2 (see picture). Allow Velcro to set-up overnight before attaching SORBER baffles to ensure a more permanent bond.
3. Attach S2216 baffles.

Additional clear panels and SORBER baffles can be added to create a complete enclosure if more isolation is needed.

www.clearsonic.com
1-800-888-6360

